

## UNIVERSAL ASSEMBLIES AND PARTS

<b>Part#</b>	<b>Description</b>	<b>Qty</b>
I1	DRIVELINE COMPLETE	1
I4	UNIVERSAL CROSS REPAIR KIT	2
I9	1-1/8" SPLINED BORE YOKE	1
I10	1-3/8" SPLINED BORE YOKE (QUICK LATCH)	1
I16	COTTER PIN FOR NON LOCKING YOKE	1
I17	CLAMP BOLT FOR 1-1/8" SPLINED YOKE	4
I19	NYLON BEARING ASSY FOR I1	4
I20	THRUST WASHER	1