

FLIGHT AND CHAIN ASSY

Part#	Description	Qty
J1	FLIGHT TUBE	16
J2	FLIGHT TUBE SPRING TOOTH	192
J3	FLIGHT CHAIN BLOCK	32
J4	FLIGHT CHAIN LOOSE SPCR PLATE	32
J5	FLIGHT CHAIN DBL CHAIN LINK PIN NO RC80	32
J6	FLIGHT CHAIN TIGHT SIDE PLATE	32
J7	FLIGHT SPRING BOLT	192
J8	FLIGHT CHAIN BLOCK BOLTS	32
J11	PB BRG	2
J12	REAR DRIVE SHAFT SHIELD	2
J13	1/2" NF X 2-1/2" HHCS W/ LOC NUT	4
J19	434 CHAIN NO RC80	
J20	433 CHAIN NO RC60	
J21	434 FLIGHT CHAIN COMPLETE W/BLOCKS NO RC80	
J22	3/8" FLT WSHR	192
J23	FLIGHT TUBE COMPLETE W/TEETH & BOLTS	16
J24	TOP FLIGHT SHAFT COMPLETE W/SPKT & BRG	1
J25	BOTTOM FLIGHT SHAFT COMPLETE W/SPKT & BRG	1
R12	1-7/16" INSERT ONLY	
PU32	BALL & SET SCREW	
J27	COTTER PINS FOR RC60	
J28	COTTER PINS FOR RC80	
J29	9 PITCH LENGTH RC80 CHAIN	
C4	CONNECTOR LINK FOR RC60	