

Application of MPL 5000 stick lube applicator GE/EMD application pedestal liner mount bracket



Fig. 1 Remove spray nozzle, bracket and hoses if equipped. Pedestal bracket as shown from spray system may be re-used for the stick system. **NOTE: MPL pedestal liner mounting bracket supplied with each set, mount to ped liner as shown.**



Fig. 2 Mount magazine assembly to bracket as shown. Set brakes to move wheel toward end of magazine to Ensure $\frac{3}{4}$ " clearance to wheel.



Fig. 3 Magazine assembly may be mounted either side of bracket depending on distance from wheel. If there is room to use four magazine bolts do so, or secure with two bolts, nuts, washers.



Fig. 4 Ensure magazine alignment to wheel is $\frac{3}{4}$ " clearance, with outside edge of magazine slightly below top of flange. Stick will be centered in throat of flange. Some stick on tread of wheel is OK.



Fig. 5 Insert lube stick as shown. Ensure spring is on spring slide and insert slide / spring assembly into the guide slots on the magazine. Hold spring slide in until pin is inserted in magazine holes.



Fig. 6 Insert lock pin, and check all fasteners to ensure they are tight. Make sure to check stick adjustment to the wheel. Stick should be adjusted into the throat of the flange. See fig 4 above.